

INSTALLATION GUIDELINES

FS-200

Foot Shower



Your FS-200 Unit has been assembled for your convenience. A crescent wrench can be used if the valve, shower head, and/or threaded connections need tightening.

To install your unit:

You will need:

- 9/16" wrench and crescent wrench
- Hammer
- Roto hammer with 3/8" drill bit

1. Stand the unit at the desired location for installation.
2. Using the base plate as a guide, mark the placement of the drill holes.
3. Drill 4, 3/8" holes, 3" deep.
4. Place unit in position, lining up base plate holes with drilled holes.
5. Insert anchor bolts in holes with washer and nut at plate surface.
(Additional stainless steel washers may be used under base plate if needed for leveling.)
6. When bolts are in place, and unit is leveled, hit the pin of the bolt with a hammer, locking it into place.
7. Tighten nuts.
8. Connect the 1/2" flexible hose to the unit with the 1/2" x close nipple.
9. Connect the water supply line to the other end of the hose.
10. Attach rubber grommet to base cover at grooves. Slide over valve to base of unit.

Overall Height: 32"



Angle Valve
Shower Head
Close Nipple

2" x 30"
Stainless
Steel Tubing

Water Supply
← Inlet

Base Plate

Base Cover with
Rubber Grommet



◀ *Our Reputation Is Stainless* ▶