

# INSTALLATION GUIDELINES

## Free Standing Units: PS-1000 / PSDF-1500 / BS-2000



1-866-746-9371

PS-1000 - Hose Bibb

BS-2000: Foot Shower & Hose Bibb

DF-1500:- Drinking Fountain & Hose Bibb Option

Height 82" (from flooring surface)

### You will need:

- 9/16" wrench and crescent wrench
- Hammer
- Roto hammer with 3/8" drill bit
- Teflon Tape

#PSDF-1500-ADA  
With Foot Shower

1. Stand the unit at the desired location for installation.
2. Using the base plate as a guide, mark the placement of the drill holes.
3. Drill 3, 3/8" holes, 3" deep.
4. Place unit in position, lining up base plate holes with drilled holes.
5. Insert anchor bolts in holes with washer and nut at plate surface. (Additional stainless steel washers may be used under base plate if needed for leveling.)
6. When bolts are in place, and unit is leveled, hit the pin of the bolt with a hammer, locking it into place.
7. Tighten nuts.
8. Connect the water supply to the 1/2" female pipe opening located at the base of the unit.
9. Place the rubber grommet onto the body and slide down towards base plate.
10. Place base cover onto the body and connect with rubber grommet. Once connected, slide them down the body to cover base and water supply.
11. Foot Shower: Install angle valve with foot shower using 2, 1/2" close nipples and Teflon tape.
12. Hose Bibb: Install into lower inlet using Teflon tape.
13. Drinking Fountain: Connect 90° arm to shower base at upper inlet using Teflon tape. Connect drinking fountain bubbler to upper portion of arm.
14. Connect Shower Body to straight valve using Teflon tape and a 1/2" x close nipple. **(Note: The word "in" is on the lower part of the valve. The body of the shower must be connected at this opening for proper operation.)**
15. Connect shower riser to upper inlet on straight valve using Teflon tape on threads.
16. Install shower head at end of shower riser. Use of Teflon tape is not needed.

### ALL UNITS COMPLETE WITH:

- 2.5 GPM Shower Head
- 1/2"x44" Stainless Steel Riser
- 1/2" FPT on/off Straight Valve
- 2"x40" Stainless Steel Base
- 9" Diameter Stainless Steel Base Cover
- Rubber Grommet
- 1/2" Close Nipple (1)
- 1/2" MPT Hose Bibb with Vacuum Breaker

### BS-2000:

- 1/2" FPT Foot Shower Angle Valve, 1/2" X Close Nipples (2)
- 1" Shower Head

### PSDF-1500

- Drinking Fountain Bubbler & Arm

New, rounded base plate for easier installation



**It is very important to winterize outdoor showers. Just like water faucets and hose bibbs, they are susceptible to freeze damage in temperatures below 32°F. The unit(s) must be drained and valves removed in extreme freezing conditions. **WARNING: FREEZE DAMAGE is NOT covered by the warranty.****